

The
**Glass
Balustrade
Company**

How To Measure A Podium Juliet Balcony

Lasyard House,
Underhill Street,
Bridgnorth,
Shropshire,
WV16 4BB


Phone number:

01746 763477

info@glassbalustradecompany.co.uk

<https://www.glassbalustradecompany.co.uk>


How To Measure A Podium Juliet Balcony



We need the measurement from the top of the door sill to the underneath of the window sill.

In order to get the correct size glass we need the size of the opening i.e. wall to wall. Also the size of the opening from sill to sill as this is sometimes different to the wall to wall. We also need to know where the internal floor is in relation to the door sill i.e. lower/higher? The glass fixings normally are positioned 100mm away from the edge of the brickwork with 75mm of glass beyond. This is usually set 50mm above the sill to allow for cleaning

If the doors have external handles, how far do they project from the face of the wall?



It is important to note that there is nothing 200mm either side of the Juliet doors to prevent fixing i.e. drainpipes etc.